



BOOMERBUGGY FOLDABLE USER MANUAL

SAFETY

For your safety, please ensure the following:

- Check brake lever, and that the brake sensors shut off power to the motor
- Check the air pressure of both front and rear tires. The correct P.S.I. is listed on each tire
- Check and make sure that your mirrors are tightened and allow for maximum visibility
- Observe all traffic rules, and do not operate in areas where motorized vehicles are not allowed.
- Make sure that your battery power is sufficient before you go out to ride
- If you bring your charger avoid shaking / rattling charger while riding.
- **Do not over charge the battery by leaving the charger in the charging port. Once the battery is fully charged remove the charger immediately.**
- **Do not try to operate the unit while charging.**
- **Do not let anyone under the age of 16 years old operate this vehicle.**
- **Do not make sharp / abrupt turns at high speeds to avoid tipping.**
- **Do not operate under the influence of any use of drugs or alcohol**
- **Do not completely submerge the unit in water**
- **Do not operate in harsh weather conditions.**

**For any questions or concerns please call
1-800-649-9320 or visit www.daymak.com**



ABOUT DAYMAK

Daymak is one of Canada's largest Alternative Vehicle providers. We design, engineer, manufacture, import and repair everything from recreational dirt Mobility Scooters, go-karts and electric golf cars to alternative transportation solutions such as Mobility Scooters electric scooters.

Our electric bicycles represent an energy-efficient and eco-friendly alternative for people who need to get around the city. They greatly increase the practicality of bicycle transportation in urban centres. Costing only a few cents to charge, an Mobility Scooter can make city life more convenient and much less expensive.

While there are many new Green technologies that are still in their infancy, electric bicycles have been developing over the last 40 years or more. Mobility Scooter technology has been dramatically refined since the introduction of the first custom-conversion bicycles. Today, electric bicycles are a supremely reliable and affordable means of transportation.

Daymak is constantly developing new eco-friendly alternative transportation strategies, led by its own Research and Development department in Toronto, Canada. We are always improving our products. Our innovative in-house engineering and quality testing provide customers with many new kinds of reliable, eco-friendly vehicles, designed to help change the lives of our customers and the world.

Daymak warranties, services, and stocks parts for everything it sells. We support our products. Please feel free to visit our website. You'll find the latest in cool transportation solutions, support for the products you've purchased and contact information.



INTRODUCTION

MOBILITY SCOOTERS

Using an electric bicycle is a great way to ride around town conveniently and economically. Mobility Scooters represent a natural progression in the development of urban transportation. Using only small amounts of electricity, Mobility Scooters have the potential to radically reduce the amount of pollution in our cities. They are also very quiet, so they do not add to the high levels of noise pollution which we often take for granted. They are easy, and usually free to park. They are unobtrusive and highly practical additions to the urban landscape.

Mobility Scooters are also inexpensive. They (currently) require no registration, no insurance, no licence and do not incur parking charges. Compared to internal combustion engines, the engines in electric vehicles have fewer moving parts and require far less maintenance. Your Daymak Mobility Scooter is the result of Daymak's years of experience, the highly trained technical skills of our staff, and careful ongoing design work by our engineers. We hope you enjoy using this product and welcome any feedback that you may have.

NEW LAWS

Most provinces in Canada, most states in the U.S.A, the United Kingdom and many European countries have new laws that permit cyclists to use electric motors to assist the regular operation. Please check with your provincial or state government to learn about your local laws.

LIABILITY

Daymak does not assume any liability for damages, loss of profits, or claims from third parties due to improper use of this product. Daymak does not assume any liability for damages due to problems with the product resulting from service by a third party that is not certified by Daymak.

The information in this guide may be subject to change without notice. For the latest information available, please contact your local Daymak dealer or visit our website. We have taken all possible measures to ensure the accuracy and completeness of the information in this guide. However, if you do find anything missing, incomplete or wrong, do not hesitate to contact us.



TABLE OF CONTENTS

- SAFETY 2
- ABOUT DAYMAK 3
- INTRODUCTION 4
- PART DIAGRAMS 6
- RIDING INSTRUCTIONS 7
- THE BATTERY 12
- CHARGING YOUR MOBILITY SCOOTER 13
- UNDERSTANDING YOUR VOLTAGE 14
- CHARGING THE BOOMERBUGGY FOLDABLE 15
- OPERATION 17
- FOLDING YOUR UNIT 19
- BRAKES 22
- TECHNICAL DATA 23
- VEHICLE IDENTIFICATION NUMBER (VIN) 24
- MAINTENANCE AND TROUBLESHOOTING 25
- SPECIFICATIONS 29



PART DIAGRAMS

DIAGRAM 1: BOOMERBUGGY FOLDABLE

This diagram illustrates the various parts of your mobility scooter. Please note that many of these parts are not user-serviceable and should be repaired only by trained professionals. This is especially true of the electrical systems and the mechanical components.



- | | |
|----------------------------|-----------------|
| 1. Throttle | 7. Motor |
| 2. Handlebar Quick Release | 8. Luggage Rack |
| 3. Handlebar Latch | 9. Battery |
| 4. Headlights | 10. Seat |
| 5. Tire | 11. Brakes |
| 6. Carrying Rail | 12. Display |

RIDING INSTRUCTIONS

This guide assumes that you already know how to operate a mobility scooter. If you have never used a mobility scooter before, we strongly recommend that you read through this guide entirely before beginning to operate.

Caution

Always make sure to be properly situated on the unit before turning it on and engaging the throttle. Failing to do so can potentially lead to injuries or damage of the vehicle.

IMPORTANT NOTES

- **Mobility scooters are Fast!** Mobility scooters are capable of traveling at higher speeds than many people are accustomed to. Use caution at all times, especially when travelling in mixed traffic. Always take into account driving and traveling conditions.
- **Obey the Law.** Be sure to follow all provincial and city traffic laws. This includes obeying stop signs, checking carefully when turning, and riding defensively. A mobility scooter is a motorized vehicle, and thus you must follow the law.
- **Stay Sober.** Never ride your mobility scooter while intoxicated. Mobility scooters can cause harm to the rider and others if not operated properly and require full attention during operation.
- **Mobility scooters are to be rode on the sidewalk unless there is no sidewalk present.** Please be mindful of all pedestrians on the sidewalk and give ample notice when passing by.



ITEMS TO CARRY WITH THE ELECTRIC MOBILITY SCOOTER

It is a good idea to carry the following items with you at all times when you ride your Mobility Scooter.

- The charger, to charge the mobility scooter in case the battery power runs out.
- 30 Amp Fuse, spares for the batteries, in case the fuses blow (if applicable).
- A lock, to secure your Mobility Scooter when you park it.

INSPECTING YOUR MOBILITY SCOOTER

Always inspect your mobility scooter before you ride it, to make sure its safety features are operating properly. Many accidents can be avoided with routine inspections. Once you are comfortable with your mobility scooter, you will be able to detect small changes in the way it feels. If anything changes between uses, make sure to have it properly examined. Also, be sure to listen for changes in the sounds your mobility scooter makes over time. Any mechanical or power issues may have effects on the sounds the mobility scooter makes.

HOLDING THE HANDLEBARS

As you would with a bicycle, place your fingers over the brake levers (if your scooter has disc/drum brakes), using the palms of your hand and your thumbs to wrap around and under the handlegrips. Doing this allows you to activate the brakes easily, by squeezing your hand, in case you have to stop quickly. Otherwise hold onto the handle bar in a manner where you can easily push the brake mechanism. This is the safe way to control your mobility scooter.

TURNING YOUR MOBILITY SCOOTER ON AND OFF

To turn on your mobility scooter, simply press and hold the power button on the display panel. You can find more detailed information in the operation section of this manual.



ACCELERATING AND DECELERATING

The throttle is typically found on the right handlebar (see operation for more information). Use this carefully when situated on the mobility scooter to go forward and release to decelerate.

Warning

Do not activate the accelerator until you are seated on the mobility scooter and are ready to accelerate. The mobility scooter can easily escape from your control, possibly injuring you or others, and the mobility may be damage.

STOPPING

Your Mobility Scooter has brakes, at the rear of your scooter. The levers attached to the handlebars, on the left activate the brakes. Pull the levers toward you to activate the brakes.

SAFETY TIPS

- When you are traveling in wet weather, water may cause your brakes to function less efficiently because it reduces friction between the brake pads and the wheels.
- Take care to slow down and give yourself more room to stop or slow if necessary.
- It is a good idea to have your brakes and brake pads checked regularly. The brake pads will eventually wear down through friction, and after significant use will have to be replaced.



SIGNALLING

THE HORN

The mobility scooter has a horn. Use this when coming close to pedestrians to warn of your passing. See the operation section for where to find your horn and how to use it.

LIGHTS

The headlight and its useful features when you are riding at night or in dark areas. They radically improve your safety on the sidewalk or road. The lights on your mobility consume some electricity. Keeping them on may reduce the maximum distance you can travel on one charge by about 5 %.

RIDING IN WET WEATHER

Your mobility scooter is designed to function in wet conditions, such as when it is raining. However, it is easy to slip when moving at high speeds. If it is very wet, be sure to avoid high speeds. When you are traveling in wet weather, water may cause your brakes to function less effectively because it reduces friction between the brake pads and the wheels. Take care to slow down and give yourself more room to stop or slow if necessary.

THE MOTOR AND WATER

Your mobility scooter is not designed to be immersed in water. Always ensure that the water level does not go above the motor, to prevent water from getting inside of it. Water in the motor can cause short-circuits and may damage the electrical systems in your Mobility Scooter.



RIDING IN COLD WEATHER

Your mobility scooter is designed to operate year-round. However, in very cold conditions or when there is a lot of snow or slush on the ground, it is possible for the motor in the mobility scooter to get wet or for the brakes to function less effectively, just as it can happen in wet weather. Below 10 degrees Celsius, the battery will not work as well as it would in warmer temperatures. While Lithium-Ion batteries perform better than Lead-Acid batteries in temperature extremes, both will experience reduced performance in cold temperatures.

Also, riding the mobility scooter in cold temperatures may require you to replace the battery sooner rather than later.

MAXIMUM LOAD

Do not exceed the maximum load capabilities of your mobility scooter. You can find the exact loading capacity listed in the technical specifications in this guide.

If you exceed the maximum load, the performance of the scooter will suffer.

Exceeding the maximum load of your Mobility Scooter could cause damage to the shocks, to the mechanism and, ultimately, even to the frame. It could also cause your motor to work too aggressively, and may cause it to burn out.

LONG-TERM STORAGE OF YOUR MOBILITY SCOOTER

If you are storing your Mobility Scooter for a long period, disconnect the circuit breaker (if applicable). This is a safer way to store the electric bicycle, as it prevents accidental activation of the mobility scooter and makes it impossible to activate it even with the key.

Please see the section titled “The Battery” for instructions on battery maintenance while your mobility scooter is being stored.



THE BATTERY

This section details what you need to know about the battery that powers your mobility scooter. Always remember to treat your mobility scooters electrical systems with respect.

BATTERY POWER

The dashboard has a battery charge indicator. When the mobility scooter is activated, the gauge will jump and indicate the currently available battery power. If the power has dropped significantly, you should charge your scooter.

DISTANCE AND POWER

Your battery has the capacity to carry you anywhere from 20+ km before it must be recharged. The ability of your battery to power your bicycle depends on many variables. These variables include the weight of the rider, the prevailing wind resistance, the rider's driving habits, the presence of steep hills and inclines, and other issues such as proper air pressure in the tires.

SAVING POWER

If you are traveling long distances, you can save a lot of electricity by using better driving habits:

- **Coasting:** When going downhill or over long, flat road surfaces, try using your e-Mobility Scooter's momentum and allow it to coast, without drawing power from the motor.
- **Stopping and Starting:** Try to avoid stop and go movements. The motor draws more power when starting from a full stop.
- **Weight:** Remove unnecessary weight from the scooter. This reduces the amount of power the motor must draw.
- **Air Pressure:** Make sure your tires have the proper air pressure. Proper pressure reduces drag on the tires and radically increases the efficiency of any vehicle.
- **Head and Tail Lights:** Turn off the lights to conserve power, if it is safe to do so. The lights will reduce the distance you can travel by about 5%.



CHARGING YOUR MOBILITY SCOOTER

Charging your scooter is a simple process. You require the following:

- The charger that came with your Mobility Scooter.
- A 110V household electrical outlet.

Charger Warning

Only use the chargers that were supplied with your mobility scooter. Using chargers that do not have specifications identical to those which came with the mobility scooter could irreparably damage your scooter's battery and electrical systems, and may cause injury.

To charge your scooter, follow these steps:

1. Turn off the mobility and remove the key from the ignition (if applicable).
2. Plug the female end of the charger cable into the charging slot on the mobility scooter.
3. Plug the male end of the charger power cable into your wall socket. This should be a 110v household electricity supply. You can also use a portable generator, if necessary, but make sure it provides 110V current.
4. Allow the mobility scooter battery to charge for the appropriate amount of time (4-8 hours).
5. Disconnect the charger when the LED light on the charger is green. The batteries have been fully charged.

If your charger's LED status light does not change from red to green over an extended period of time, for perhaps more than 14 hours, and the battery is very hot, the battery or charger may need replacing. Stop charging and bring both to your Daymak dealer immediately. Do not overcharge the battery.



UNDERSTANDING YOUR VOLTAGE

Electric scooters primary power is understood as voltage. This number in short is how powerful your unit is, and as it dips down when the unit will no longer be able to perform. Depending on your unit’s voltage and battery type (Lithium vs Lead Acid) will effect the range of voltage between what is fully charged and when it exceeds the low voltage threshold.

LOW VOLTAGE THRESHOLD

Your unit will try to protect the battery by preventing the motor from drawing power below the Low Voltage Threshold. By doing this it will significantly increase the life expectancy of your unit. If you find that your motor starts cutting off at a certain speed or not engaging at all it may be because your voltage is dropping past the threshold point and needs to be charged. To see what your voltage threshold you can check on it via the bluetooth APP (if applicable) and you can check it out using this chart.

VOLTAGE CHART

VOLTAGE	LEAD ACID		LITHIUM ION	
	FULL CHARGE	LOW VOLTAGE	FULL CHARGE	LOW VOLTAGE
24V	27V	21V	29.4V 7S	20V 7S
36V	40V	32V	42V 10S	28V 10S
48V	53V	42V	54.6V / 58.8V 20S 21S	37V / 40V 20S 21S
60V	67V	53V	67.2 / 71.4V 16S 17S	45V / 48V 16S 21S

LITHIUM FULL/LOW VOLTAGE READING

Depending on the way your lithium battery’s composition will impact what the low voltage and full charge reading should be. Underneath each reading on the above chart shows a number and a “S” this represents how many series are in your battery pack. To know the exact series of your battery contact your local Daymak dealer.



CHARGING THE BOOMERBUGGY FOLDABLE

The Boomerbuggy Foldable comes with a lithium Ion battery that can be charged both inside and outside of the unit.

- 1) Charge Port - Plug your charger into this port to charge the battery. Once the Mobility Scooter is charging the charger will glow red. When the unit is fully charged the charger will glow green and then your Mobility Scooter is ready to go.
- 2) Battery Lock - The Battery can be locked / unlocked from the frame. Turn it clockwise to lock it and counterclockwise to unlock it. Once unlocked you can pull the battery out by the handle



Warning

Do not leave the Roadstar Deluxe charging for long periods of time after it is fully charged. Once the Mobility Scooter is charged unplug it ASAP.



BATTERY CARE

Follow these suggestions to maintain your battery's optimal performance. If you do not follow these suggestions, your battery may lose its ability to maintain a charge and might have to be replaced sooner than would otherwise be necessary.

- **Charge it:** Charge your battery immediately after riding it.
- **Full Charge:** Do not allow the battery to run down completely and lie in storage without a charge. This significantly reduces the battery's lifespan and may cause damage.
- **Keep it Charged:** When being stored, charge the battery occasionally to make sure its power supply does not run down. Charging it once every 21 days should be sufficient.
- **Storage Conditions:** Store the battery on a flat, cool, dry surface. Do not allow the battery temperature to drop below 10 degrees Celsius for extended periods of time.

Warning

DO NOT place your Lead-Acid battery on concrete. Concrete drains the battery's power and will neutralize the lead-acid. Placing the battery on concrete for any length of time will likely result in the battery being drained of power and possibly losing its ability to store electricity.

COLD WEATHER AND YOUR BATTERY

Below 10 degrees Celsius, the battery will not work as well as it would in warmer temperatures. While Lithium-Ion batteries perform better than Lead-Acid batteries in temperature extremes, both will experience reduced performance in cold temperatures.

Also, repeatedly riding the Mobility Scooter in cold temperatures may cause your battery to have to be replaced sooner.

REPLACEMENT AND DISPOSAL

After approximately 300 charges, a lead-acid battery will need to be replaced. A lithium-ion battery will last approximately 1000 charges. When the battery has to be replaced, you will notice that your battery cannot carry as much of a charge as it could initially.

Contact your local Daymak dealer to purchase a new battery.


When replacing your battery, dispose of it at a proper municipal battery recycling facility. If none is available, please contact your local Daymak dealer.



OPERATION

Congratulations on your new Boomerbuggy Foldable mobility scooter. On the Boomerbuggy Foldable you will find a display on the right hand side. These are the features.

- 1) Horn - Press this button to honk the horn.
- 2) Mode - Press this to choose which speed you are on.
- 3) Mode Lights - If no lights are showing the unit will not move. This will light up over low medium and high to show the speed you will choose.
- 4) Battery Meter - Shows how much power you have left.
- 5) Light - Press this to turn on the light
- 6) Light signal - Indicates whether the light is on or off
- 7) ON / OFF - Press and hold this to turn the unit off or on
- 8) Brakes - Press this lever to engage the brakes.



RIGHT HANDLEBAR

- 1) Throttle - Rotate this towards you to engage the Boomerbuggy Foldable
- 2) D/R - Choose from going in forward or Reverse.



BRAKES

The Boomerbuggy Foldable comes with rear brakes that you can activate on by squeezing the handle.

To engage the brake lock you need to pull the brake handle and the brake lock at the same time until it holds the brake in the on position.

Pull the brakes even tighter to release it.



HANDLEBAR

The Boomerbuggy Foldable comes with adjustable handlebars to set the height. To adjust the handlebar take the quick release latch and open it as seen here and then adjust the height that you desire.



FOLDING YOUR UNIT

To fold the Boomerbuggy Foldable follow these steps.



Next, with your latch free, pull this down and apply pressure on it until the handlebar folds down.



After, fold the back part of the seat down



FOLDING YOUR UNIT (CONTINUED)

Carefully lift the lever on the back of the seat while holding the seat and lower it down.



You must do the reverse of this procedure to unfold the Boomerbuggy Foldable

CHARGER

The charger as seen here as a LED light on it. When it is plugged in and charging the light will turn red. Once it is finished charging it will turn green. Once the Boomerbuggy Foldable is done charging unplug it as soon as possible.



LUGGAGE RACK

On the back of the luggage rack you will see a knob like this one. Pull this outwards while pulling the luggage rack to get additional carrying space.



CARRYING RAIL

The Boomerbuggy Foldable also comes with a carrying rail. On the under side of the unit pull the pin that locks it into place and lift the bar upwards until it locks into place. Use this to wheel the unit as if it was a stroller.




BRAKES

The Boomerbuggy Foldable comes with rear brakes that you can activate on by squeezing the handle.

To engage the brake lock you need to pull the brake handle and the brake lock at the same time until it holds the brake in the on position.

Pull the brakes even tighter to release it.



TECHNICAL DATA

This section provides you with the technical specifications for your Mobility Scooter.

THE MOTOR AND WHEEL ASSEMBLY

The Roadstar Deluxe has a magnetic DC brushless motor on the rear wheel hub. This type of motor has excellent low-end torque and high efficiency when working within its range. Note that while the motor is very quiet, it does produce some noise. Also attached to the rear hub are speed reduction gear and the speed free clutch..

THE CONTROLLER

Daymak pioneered the development of intelligent component control in Mobility Scooters. The Daymak Drive technology developed by Daymak is the brain of your Mobility Scooter. It allows your Mobility Scooter to achieve faster acceleration, to climb steeper hills, and to save energy.

The electronic controller is located under the seat assembly. This controller efficiently regulates the speed and electronic functions of the bicycle. It allows for stepless speed adjustment, shuts off the motor when the brakes are activated, has low voltage protection and has fuses to prevent excess current from damaging the Mobility Scooter's systems. This can all be regulated by Bluetooth app.

THE BRAKES

REAR BRAKES

The rear brakes on your mobility scooter are drum brakes. These provide a good friction-grip when they are activated and should be used first before the front brakes.



VEHICLE IDENTIFICATION NUMBER (VIN)

Your unit comes with a Vehicle Identification Number. You should write this down and keep it somewhere safe in case of theft of your unit. This is also required for registering your warranty on the warranty section of Daymak.com. To find the VIN on your Boomerbuggy Foldable look on the frame behind the headlight for numbers ingraved on the frame. That is your VIN.



MAINTENANCE AND TROUBLESHOOTING

This section outlines problems you may have and solutions you may be able to use.

Many of the parts in this product are not user-serviceable and should be repaired by trained professionals. This is especially true of the electrical systems and the mechanical components. Alteration of these components voids the warranty.

TIRE PRESSURE

Maintain the air pressure in your tires at the appropriate level. If the air pressure is too low, your mobility scooters performance will suffer and it will become damaged more easily.

Cold weather and lower temperatures will cause the air pressure in your tires to drop, and warmer weather will cause it to increase, even if there are no leaks in the tire tube. To replace the air in your tires, follow this procedure:

1. Identify the required pressure by examining the text along the side of the tire rim. This text should indicate the recommended pressure for your tire.
2. Locate the air valve on the inner surface of the tire rim.
3. Remove the valve cap and place in a secure location.
4. Place the nozzle end of an air pump (hand-power or mechanical) over the valve.
5. Pump up the air in the tire, being careful not to let the pressure go above the level prescribed on the side of the tire wall.
6. Remove the pump nozzle from the air valve without allowing much air to escape from the tire.
7. Replace the valve cap on the air valve.

Maintaining the proper air pressure will allow you to travel much further on a single charge, because the motor will not have to work as hard to move the Mobility Scooter.



REPLACING FLAT TIRES

Replacing flat tire tubes is a more complicated and labour-intensive process with Mobility Scooters than it is with regular bicycles. It requires proper tools, more skill and more patience. The front wheel is easier to service when changing a flat tire than the rear wheel, as the rear wheel is connected to the hub motor and other mechanical parts.

Unless you are very familiar with the mechanical components of the rear motor, attempting to change a flat rear tire may cause serious problems. Please contact your Daymak dealer for specific instructions on how to remove your wheel and tires safely, and how to replace the tubes. It may be easier – and safer - to have the tubes replaced by your Daymak dealer.

THE MOTOR

Do not service the motor yourself. Bring the mobility scooter to your Daymak dealer for service. The motor in your mobility scooter is a highly complex and fine-tuned mechanism. Repairing it requires significant expertise. **We suggest maintenance every 100 running hours or so.**

BRINGING IN YOUR MOBILITY SCOOTER FOR SERVICE

Do not attempt to service the electronic or mechanical parts of your mobility scooter unless you are absolutely sure of what you are doing and have a solid understanding of electrical and mechanical equipment. If your mobility scooter is not performing properly, disconnect the circuit breaker (if applicable) and bring the mobility scooter to your local Daymak dealer. **Do not store the mobility scooter without disconnecting the circuit breaker.**

Liability

Daymak will not be held responsible for damage or injuries resulting from errors resulting from improperly serviced parts.



CLEANING

Cleaning is extremely important this will ensure your mobility scooter will serve you for a long time. In the long run, it will save you money and a lot of time waiting for the Mobility Scooter to be repaired. You should clean your mobility scooter weekly.

Do not use aggressive power jets or water sprays when washing the mobility scooter and keep water off the battery as much as you can. Clean gently but thoroughly and make sure that all the outer casing of the electric parts are dry and clean.

Remove any dirt, debris, sand, mud, grit, grime that got caught on the Mobility Scooter and dry it off.

While cleaning, it is a good opportunity to look closely for a worn, loose, cracked, rust, teared or damaged parts. Buckled paint can also be a hint for some parts that need closer inspection.

LUBRICATING

It is also recommended to lubricate, levers, cables, etc. A clean, lubricated mobility scooter tends to be faster, smoother and quieter. It's like having a little extra push for free.

Apply the lubricant to the different parts and let it sit a few minutes and then wipe off the excess lubricant with a rag. After a while, clean the different parts with a degreaser to remove any excess dirt that has been collected.

WEATHER

Don't leave the mobility scooter out in the rain or snow.

Store it somewhere dry and out of direct sunlight. Overheating the batteries, for example, can cause problems.

Do not open up casings, chargers, etc as you are unlikely to be able to reseal them effectively afterward, making them more susceptible to water damage and other extreme weather conditions.

Batteries should be removed from the mobility scooter if not used and charged once a month regardless of usage if possible.



SCHEDULE

The frequency of maintenance depends on how much you ride and under which conditions. Recreational riders needs far less maintenance then off-road riders. The harder you ride, the more you have to take care of your Mobility Scooter if you want it to last. There are various time intervals for proper maintenance. Quick maintenance should be done before & after every ride.

Time after Purchase	Action Suggested
Everytime before you ride (The 60 Second Check)	Check tire pressure, check brakes that they work, check lights, check bolts (make sure everything is tight), check battery gauge. Do not ride the unit unless everything is functional and proper
30 Days (every month)	Completely clean the unit, including the dust on the motor and under the seat. Check for any abnormal wear and tear or alignment problems.
90 Days (every 3 months)	Inspect frame and fork for paint crack or bulgest that may indicate frame or part damage; pay particular attention to all frame joints. Check wear and tear on tires. Check range of battery.
180 Days	Inspect all components on the unit. Check that connections are nice and tight. Look inside where your controller is and clean in detail. Check that all plugs are clean. Go over every bolt and nut in your unit.
360 Day (every 12 months)	Bring the unit for a complete tune-up. Varying on the unit the shop should complete a battery discharge, tires should be changed depending on wear and tear. All connections should be checked for rust and loosness. All components should be checked including charged, ignition, and gauges.



SPECIFICATIONS

Name	Boomerbuggy Foldable
Motor	250W
Voltage	36V
Amp Hour	7.7AH
Watt Hours	280Wh
Battery Life	1000 cycles
Battery	Lithium Ion
Removable Battery	Only During Replacement
Charger	42V 1.5A 110V
Charge Time	4 - 6 Hours
Lights	LED
Max Load	225 lbs.
Assembled Weight	55 lbs.
Assembled Length	42"
Assembled Width	17"
Assembled Height	43"
Seat Height	N/A
Seat Width	N/A
Seat Length	N/A
Boxed Weight	31 lbs.
Boxed Length	43
Boxed Width	6
Box Height	20
Range	Up to 25 km
Speed	25 km/h
Climbing Incline	15 degrees
Front Wheel	200x50
Rear Wheel	10 x 2.5
Gauges	Battery Level / Speedometer
Ground Clearance	4"
Wheel Base	33"
Battery Weight	4 lbs.
Rear Brakes	Disc Brakes



Name	Boomerbuggy Foldable
Front Brakes	N/A
Ignition	No
Front Shocks	N/A
Rear Shocks	N/A
Controller	Standard
Pedal Assist	N/A
Speed Levels	3 Speeds
Throttle	Push
Cruise Control	No
Display	LED
Frame Size	N/A
Rear / Basket Storage	No
Under Seat Storage	No
Rear / Basket Storage Volume	N/A
Under Seat / Glove Storage	N/A
MP3	No
Occupancy	1
Alarm	No
Steering Lock	No
Center Kickstand	No
Foldable	Yes
Folded Dimenison	42" x 17" x 20"



THANK YOU FOR CHOOSING DAYMAK

